


ダイス厚	1.0		1.5		2.0		2.5		3.0		3.5
ダイス幅	0.7	1.0	1.3	1.6	1.9	2.2	2.5	2.8	3.1	3.4	3.7
PAD-11	●	●	●	●	●	●	-	-	-	-	-
PAD-12	-	-	-	●	●	●	●	●	●	-	-
PAD-13	-	-	-	-	-	-	●	●	●	●	●



■ ダイス厚 = バレル長
■ ダイス幅 = バレル幅

※ダイス幅は工具本体に印字されている数値です。

ダイス厚	1.7		1.8				2.0		2.5			
ダイス幅	1.0	1.4	1.6	1.9	2.2	2.5	1.6	1.9	1.6	1.9	2.0	2.3
PA-09	●	●	-	-	-	-	●	●	-	-	-	-
PA-20	-	-	-	-	-	-	-	-	●	●	●	●
PA-21	-	-	●	●	●	●	-	-	-	-	-	-